

Instructions on how to move the C00 card on the 861 V6

Courtesy of Hitchhiker Colin

There is an Meridian bulletin titled "Concession Layout for 861 V6" which recommends a position for the C00 card

These instructions detail the steps required to move the C00 board to the preferred position

1. Set aside at least one hour so that you will not be rushed
2. Ensure you have a screwdriver with Torx, Allen key and Phillips bits
3. Remove the 4 screws on each side of the glass and aluminium cover using an Allen key bit
4. Remove the cover by sliding towards the rear
5. Remove the smaller black Torx screws, four at each side of the 861 at the top of the sides, in two pairs. Not the larger silver Phillips head screws that hold the card slides in place. You may want to slightly loosen these larger screws though to make top removal easier although I did not find that necessary.
6. Remove the two screws on the top of the cover and then remove the top metal cover by lifting the corner with a flat screwdriver
7. Remove the Torx screws securing the C00 card, the small vented blanking panel next to it and the two blanking plates to the right of the IE44 card
8. Remove the vented blanking panel which should enable you to pull the C00 card back a small amount
9. You should see a ribbon cable connected to the card.
10. Note the orientation of the cable. This is **very important** as this connector is not keyed.
11. Remove the cable
12. Pull the C00 card out
13. Remove the two blanking plates from the slot next to the IE44 card
14. Pull the ribbon cable from the slot that it is in and insert it into the slot next to the IE44 card
15. Insert the C00 card partially and reconnect the ribbon cable as it was before
16. Plug the C00 card in fully
17. Replace all the blanking plates and screws
18. Replace the top cover and case
19. Plug everything back in, pour yourself a glass of wine and enjoy the music!