

Addendum – Progressive option for 596 and 800


This Addendum describes how to configure the progressive output on versions of the 596 and 800 fitted with this option.

To set the progressive output options

With the component progressive option fitted, the **Video setup** menu includes an additional **Progressive out** option to allow you to configure the Gamma correction, sharpness, and output mode (596 only) to suit your display.

- Highlight **Progressive out** in the **Video setup** menu, and press **Enter**.

The **Progressive output** menu is displayed:



- Press **▲** or **▼** to highlight the option you want, and press **Enter**.

The **Gamma correction** affects the display brightness, and can be set to 1.0, 0.8, 0.9, or 1.1.

The **Sharpness** can be set to **Off**, **Low**, **Medium**, or **High**.

The **Output mode** option is only provided on the 596, and can be set to **Interlaced** or **Progressive** to select which outputs you want to use. On the 800 the interlaced and progressive outputs are both available simultaneously.

Note: Due to restrictions imposed by the standard, the progressive output will be disabled when playing copy-protected PAL discs.

DCDi is a trademark of Faroudja, a division of Sage, Inc.